

# TIMBERWALL

**For interior use only.**

## **STEP 1 – ACCLIMATIZE YOUR TIMBERWALL PRO**

Acclimatize the wood pieces at a temperature between 18° and 30° Celsius (65°F and 85°F) for 72 hours or longer prior to installation. Maintain the indoor relative humidity between 40% to 60% at all times.

**TIMBERWALL PRO** real solid wood collections will respond to humidity variations by expanding and contracting in width, length and thickness. The manufacturer cannot be held liable for any movement in the planks.

Please note: This product is not recommended to be used in wet, damp and high humidity areas or near intense heat.

## **STEP 2 – PROJECT SITE/INSPECTION AND CLEANING SURFACES**

The surface should be completely dry and structurally capable of supporting the **TIMBERWALL PRO**. Identify the supporting studs before starting the installation.

## **STEP 3 – INSTALLATION**

Apply a bead of construction adhesive on the back of the first plank. Ensure the first plank is level and plumb. Face nail the first plank, spacing the nails 24 inches apart.

Continue to add planks to the wall to the adjacent plank leaving a 1/8-inch gap at all corners for expansion and contraction. Use construction adhesive and finishing nails to secure each piece on the wall. For superior strength, it is best to drive nail into stud every 16 to 24 inches when possible. It may be necessary to trim the last piece to fit into the corner.

**[www.timberwall.co](http://www.timberwall.co) / [info@timberwall.co](mailto:info@timberwall.co)**